



LynxTouch



- Panic Buttons:** Hold Panic key down for four seconds
- Door Chimes:** Press (Settings) then (Chime)
- Status:** Press * if keypad shows NOT READY to view open zones
- Arm AWAY:** Press (AWAY ICON) + Master Code
- Arm STAY:** Press (STAY ICON) + Master Code
- Instant Arm:** Press tab under (Arm Away ICON) to select Delay or Instant then (Away or Stay ICON) + Master code
- Quick-Arm:** (If Enabled) Press Arm Away/Stay ICON then select (Quick Arm)
- Disarm:** Press (Disarm ICON) + Master Code
- Bypass:** Main user screen Press (Back tab) then (Zones) select zone then (Bypass) + Master code (Back Arrow) then arm system
- Reset Smoke:** 4-digit code + 1 (OFF) twice to turn off siren and reset smoke
(If this does NOT reset smoke detector set for service, smoke is bad)
- Volume level:** Press (Settings) then select desired level + (Save)
- Brightness:** Press (Settings) then select desired level + (Save)
- Contrast:** Press (Settings) then select desired level + (Save)
- Voice Toggle:** Press (Settings) then select (Voice) + (Save)
- Ringer:** Press (Settings) then select (Ringer) + (Save)